TOP AND CONSOLE PARTS

29" ELECTRIC DRYER

For Models: NED5400TQ0

(White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

TOP AND CONSOLE PARTS

For Models: NED5400TQ0

(White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10088970	Instruction Installation
	W10088771	Use & Care Guide
	8576817	Wiring Diagram
	W10089173	Sheet, Cycle Feature
2	3401684	Wire, Jumper (Black)
3	693995	Screw, Hex Head
4	8271365	Cap, End (L.H.)
5	8274261	Panel, Rear Console
6	388326	Screw, Console
7	694419	Buzzer, Mini
8	8271359	Cap, End (R.H.)
9	3399639	Switch, Temperature
10		Screen, Lint
	8558463	White
11	8536939	Clip, Spring
12	8533971	Screw, 8−18 x 5/16
13	688983	Screw, 8−18 x 5/8
14	8533951	Screw, Grounding
15	3395683	Connector (Motor)
16	8557930	Top
17	W10110047	Knob, Control (1)
18	3394427	Clip−Harness
19	W10110050	Knob, Push−To−Start
20	3401144	Connector, (PTS Relay)
21	3979617	Timer, 60 Hz.
22	W10086673	Panel Control
23	8539893	Wire, Jumper (Temperature)
24	8271418	Bracket, Control
25	W10110048	Timer−Knob Assembly
26	3936144	Connector
27	3398095	Switch, Push−To−Start
28	94614	Terminal
29	3347243	Connector
30	357213	Nut, Push−In (2)
31	8576503	Harness, Wiring
33	3397269	Connector (Timer)

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

CABINET PARTS

For Models: NED5400TQ0

(White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

CABINET PARTS

For Models: NED5400TQ0

(White)

Illus. No.	Part No.	DESCRIPTION
1	8066217	Hinge, Top (2)
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, 8−18 x 3/8
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	3404162	Clamp−Motor (W/Shield)
7	3396805	Panel, Rear
8	3403630	Plug, Strike
9	3397659	Block, Terminal
10	3406107	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	3404413	Plug, Hinge Hole
13	660658	Clamp, Motor
14	3393008	Screw, 10−16 x 1/2
15	3394083	Clip, Front Panel (2)
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length Package of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)
18		Cabinet (Includes Illus. 4)
	8530603	White
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21		Panel, Front
	3403444	White
22	8066184	Pulley, Motor
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
25	3405246	Seal, Door
27	342055	Screw, 8−18 x 1/2
28	3405514	Hinge, Door
29	8066206	Motor Assembly 60 HZ.
30	3400500	Bolt, 5/16−18 x 3/4
31	348780	Base, Motor
32	W10131364	Belt Drive
33	3403431	Strike, Door
34	691366	Idler & Pulley Assembly
35	3402341	Door, Rear
36		Door, Front
	3402335	White
37		Handle, Door
	3405184	White
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)
40	697776	Screw, 10−32 x 5/8

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

BULKHEAD PARTS

For Models: NED5400TQ0

(White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

BULKHEAD PARTS

For Models: NED5400TQ0
(White)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	487909	Screw, 8−15 x 1/2
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal−Bias
9	3977393	Thermal, Cut−Off (Includes Illus. 15)
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	8541818	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
16	3977373	Bracket, Drum Light
17	3403585	Element, Heater
18	8066086	Drum Hole Plug
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	489463	Screw, 8−18 x 5/8
21	3390647	Screw, 8−18 x 1/2
22	339956	Seal
23	3403636	Baffle, Drum (1)
24	90296	Clip
25	3976434	Bracket, Support
26	692490	Baffle, Drum (2)
27	695587	Drum−Assembly
28	3406130	Seal, Rear Drum
29	W10109200	Screw, 11−16 x 3/4
30	692526	Ring, Bearing (2)
31	3403634	Scocket, Assembly
32	3403413	Bulkhead
33	3406124	Bulb
34	3402841	Lens, Drum Light
35	3359452	Nut, 3/8−16
36	348197	Washer, Support
37	3397590	Roller, Support
38	3399507	Shaft, R.H.
39	3399506	Shaft, L.H.
41	690997	Ring, Tri

OPTIONAL PARTS (NOT INCLUDED)

For Models: NED5400TQ0
(White)

Illus. No.	Part No.	DESCRIPTION
		ACCESSORY PARTS
	279948	Kit, Dryer Repair
	3406839	Dry Rack
	8522199	Kit, Dryer Vent Testing
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	4392901	Biscuit
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit(Uncut)